



CrossFilm™ Permeation Testing

100% PTFE MATERIALS FOR FLOATING ROOF SEAL APPLICATIONS

PTFE-coated fiberglass materials have been used for years in the floating roof seal industry. PTFE coatings, however, are prone to cracking. As the table shows below, a nonporous PTFE-coated fiberglass material is still permeable to vapors because of the inevitable cracks in a coated surface. Laminating a PTFE film onto the surface of a PTFE-coated fiberglass material will greatly diminish the permeation of a material.

A fiberglass material is brittle. Broken filaments of a fiberglass material will destroy coated and laminated PTFE surfaces very quickly when subjected to handling and movement. As you can see from the testing below, a standard PTFE-coated fiberglass material, viewed as a nonporous material in the industry, becomes porous after one hour of flexing. After movement, tiny holes have been created in a fiberglass material that allow the escape of vapor.

A CrossFilm™ material is mechanically-capable; it does not require a fiberglass reinforcement. Therefore, a CrossFilm™ material is 100% PTFE.

As shown in the table, CrossFilm™ 2105 and CrossFilm™ 2109 are nonporous and non-permeable to start. After one hour of flexing, fiberglass-reinforced materials become porous to vapors. The CrossFilm™ materials retain full vapor barrier capability, even in an extended 8 hour permeation test. This remains true even after another hour of flexing.

CrossFilm™ materials are simply the safest and most reliable materials for vapor containment in floating roof seal applications. In addition to excellent flexing properties, CrossFilm™ materials are guaranteed to be corrosion-free and compatible with any chemical environment.

Material	Isobutylene Permeation Testing	Isobutylene Permeation Testing After One Hour of Flexing
PTFE-coated fiberglass (0.010" thick)	0.5 to 17 ppm (20 minute test duration)	Sample became porous after flexing
PTFE-coated fiberglass with 0.002" thick PTFE films laminated to both sides (0.010" thick)	0 to 1.0 ppm (20 minute test duration)	Sample became porous after flexing
CrossFilm™ 2105 (0.005" thick)	0 ppm (20 minute test duration)	0 ppm (8 hour test duration)
CrossFilm™ 2109 (0.009" thick)	0 ppm (20 minute test duration)	0 ppm (8 hour test duration)

*CrossFilm™ is a trademark of TEXTILES COATED INTERNATIONAL. Patents worldwide. This information is supplied in good faith is based on information currently available. TCI makes NO WARRANTIES, EITHER EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTIES FOR FITNESS, OR USE FOR A PARTICULAR PURPOSE, OR ANY MERCHANTABILITY OR AGAINST INFRINGEMENT OR THE LIKE, unless expressly set forth herein.